


Our associates will ensure the tool works properly before you leave the store. If you experience issues with the tool while completing your project, simply bring it back to the Tool Rental Center to get a replacement. If you purchase Damage Protection at the time of your rental, you are not responsible for repair costs for tools that break due to normal use.





16in. Surface Cleaner

Owner's Manual

 **WARNING:** Read carefully and understand all ASSEMBLY AND OPERATION INSTRUCTIONS before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

Item #6133509

READ & SAVE THESE INSTRUCTIONS

Table of Contents

Intended Use.....	4
Packaging Contents.....	4
Technical Specifications	4
Important Safety Information	4
Specific Operation Warnings	6
Before Each Use.....	6
Operating Instructions.....	6
After Each Use.....	7
Maintenance	7
Troubleshooting.....	8

Intended Use

This surface cleaner is designed to clean a variety of outdoor surfaces such as concrete, asphalt, paving stone walkways pool decks etc. The cleaner connects to a pressure washer rated up to 4000 PSI, 10 GPM with fluid temperatures up to 212° F.

Packaging Contents

- #16" Surface Cleaner (1)
- Manual (1)
- Replacement Nozzles (2)

Technical Specifications

Property	Specification
Cleaning Width (in)	16
Max. PSI	4000
GPM	10
Material	Stainless-steel
Caster Type	Swivel
Temperature Capacity (°F)	212

Important Safety Information

⚠️WARNING

WORK AREA SAFETY

- Inspect the work area before each use. Keep work area clean, dry, free of clutter, and well-lit. Cluttered, wet, or dark work areas can result in injury. Using the product in confined work areas may put you dangerously close to cutting tools and rotating parts.
- Do not use the product where there is a risk of causing a fire or an explosion, e.g., in the presence of flammable liquids, gases, or dust. The product can create sparks, which may ignite the flammable liquids, gases, or dust.
- Do not allow the product to come into contact with an electrical source. The tool is not insulated, and contact will cause electrical shock.
- Keep children and bystanders away from the work area while operating the tool. Do not allow children to handle the product.
- Be aware of all power lines, electrical circuits, water pipes, and other mechanical hazards in your work area. Some of these hazards may be hidden from your view and may cause personal injury and/or property damage if contacted.

⚠️WARNING

PERSONAL SAFETY

- Stay alert, watch what you are doing, and use common sense when operating the tool. Do not use the tool while you are tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating the tool may result in serious personal injury.
- Dress properly. Do not wear loose clothing, dangling objects, or jewelry. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewelry, or long hair can be caught in moving parts. Air vents on the tool often cover moving parts and should be avoided.
- Wear the proper personal protective equipment when necessary. Use ANSI Z87.1 compliant safety goggles (not safety glasses) with side shields, or when needed, a face shield. Use a dust mask in dusty work conditions. Also use non-skid safety shoes, hardhat, gloves, dust collection systems, and hearing protection when appropriate. This applies to all persons in the work area.
- Do not overreach. Always keep proper footing and balance.
- Remove keys or wrenches before connecting the tool to an air supply, power supply, or turning on the tool. A wrench or key that is left attached to a rotating part of the tool may cause personal injury.
- Secure the work with clamps or a vise instead of your hand when practical. This safety precaution allows for proper tool operation using both hands.

⚠️CAUTION

PRODUCT USE AND CARE

- Do not force the product. Products are safer and do a better job when used in the manner for which they are designed. Plan your work and use the correct product for the job.
- Check for damaged parts before each use. Carefully check that the product will operate properly and perform its intended function. Replace damaged or worn parts immediately. Never operate the product with a damaged part.
- Do not use a product with a malfunctioning switch. Any power tool that cannot be controlled with the power switch is dangerous and must be repaired by an authorized service representative before using.
- Disconnect the power/air supply from the product and place the switch in the locked or off position before making any adjustments, changing accessories, or storing the tool. Such preventive safety measures reduce the risk of starting the tool accidentally.
- Store the product when it is not in use. Store it in a dry, secure place out of the reach of children. Inspect the tool for good working condition prior to storage and before re-use.
- Use only accessories that are recommended by the manufacturer for use with your product. Accessories that may be suitable for one product may create a risk of injury when used with another tool. Never use an accessory that has a lower operating speed or operating pressure than the tool itself.
- Keep guards in place and in working order. Never operate the product without the guards in place.
- Do not leave the tool running unattended.

Specific Operation Warnings

⚠WARNING

- DO NOT exceed the rated PSI capacity.
- Keep body parts clear of nozzle heads and away from skirt while operating the machine.
- DO NOT lift the surface cleaner from the surface or point nozzle heads at people while operating.
- Wear the proper safety gear including ANSI Z87.1 approved safety glasses.
- Use only on hard level surfaces.
- No alterations shall be made to this product.
- Only attachments and/or adapters supplied by the manufacturer shall be used.
- Not for use by or around children.

Before Each Use

⚠WARNING

Perform the following inspections before each to ensure the cleaner is working properly.

- Check for any worn or damaged parts. Replace any such part before using the cleaner.
- Check that all the parts are tightly fastened. Tighten any that are loose.
- Check that the casters swivel and roll smoothly. Repair or replace any that don't function properly.
- Check that the swivel and sprayer arm rotate smoothly.
- Use a low-pressure water connection to check that the sprayer nozzles are clear and spray correctly. If either do not, replace or clean the non-working nozzle (see maintenance section for the steps).

Operating Instructions

⚠WARNING

- Do not use the surface cleaner with a pressure washer that has a fluid delivery greater than 4000 PSI, 10 GPM, and 212° F. Fluid delivery above these parameters may overload the cleaner and cause damage to components and possibly person injury.
- Do not tilt the surface cleaner up off any of the casters while in use. Operating pressure very high and wildly spraying fluid that may cause personal injury and property damage.

1. After before-use inspections, place the cleaner at the edge of the surface to clean.
2. Bring a pressure washer to the area.
3. Connect the surface cleaner hose at the handle to the pressure washer hose.
4. With one hand on the surface cleaner handle, start the pressure washer.
5. Slowly walk behind the surface cleaner watching for good cleaning action.

6. When cleaning is complete, stop the pressure washer. When fluid pressure is released through the sprayer nozzles, disconnect it from the surface cleaner.

After Each Use

⚠WARNING

Perform the following inspections after each use to clean the cleaner and ready it for the next use.

- Clean out any dirt or foreign material from under the housing and the casters. If necessary, use a cloth or sponge to wash the surface cleaner and rinse it with tap water.
- Check for loose parts and any damage.

Maintenance

⚠WARNING

- Disconnect the surface cleaner from a pressure washer and ensure that the cleaner is not pressurized before performing and inspections, maintenance or adjustments to avoid any wildly spraying fluid that may cause personal injury and property damage.

Maintain the product by adopting a program of conscientious repair and maintenance in accordance with the following recommended procedures. It is recommended that the general condition of any tool be examined before it is used. Keep your tool in good repair. Keep all cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control. Keep handles dry, clean, and free from oil and grease. Also refer to the engine manufacturer's instruction manual for additional information about engine maintenance. The following chart is based on a normal operation schedule.

Maintenance Interval	Maintenance Point
Daily after operating	<ul style="list-style-type: none"> a. Turn off electricity equipment b. Keep product inner wall and brush under water to flash dirt away inside and outside c. Wipe water stains off d. Store under dry and ordinary room temperature
After the first 20 operating hours	<ul style="list-style-type: none"> e. Clean nozzle regularly f. Remove dirt attached on nozzle
After the first 50 operating hours or every week	<ul style="list-style-type: none"> g. Check screw or nut about stability h. Abnormal noise and shake may reflect more serious problem on product